

Error control

An Engineering Approach to Computer Networking

CRC

- Detects
 - ◆ all single bit errors
 - ◆ almost all 2-bit errors
 - ◆ any odd number of errors
 - ◆ all bursts up to M , where generator length is M
 - ◆ longer bursts with probability 2^{-m}

Implementation

- Hardware
 - ◆ on-the-fly with a shift register
 - ◆ easy to implement with ASIC/FPGA
- Software
 - ◆ precompute remainders for 16-bit words
 - ◆ add remainders to a running sum
 - ◆ needs only one lookup per 16-bit block

Software schemes

- Efficiency is important
 - ◆ touch each data byte only once
- CRC
- TCP/UDP/IP
 - ◆ all use same scheme
 - ◆ treat data bytes as 16-bit integers
 - ◆ add with end-around carry
 - ◆ one's complement = checksum
 - ◆ catches all 1-bit errors
 - ◆ longer errors with prob $1/65536$

Packet errors

- Different from bit errors
 - ◆ types
 - ◆ not just erasure, but also duplication, insertion, etc.
 - ◆ correction
 - ◆ retransmission, instead of redundancy

Types of packet errors

■ Loss

- ◆ due to uncorrectable bit errors
- ◆ buffer loss on overflow
 - ◆ especially with bursty traffic
 - for the same load, the greater the burstiness, the more the loss
 - ◆ loss rate depends on burstiness, load, and buffer size
- ◆ fragmented packets can lead to error multiplication
 - ◆ longer the packet, more the loss

Types of packet errors (cont.)

- Duplication
 - ◆ same packet received twice
 - ◆ usually due to retransmission
- Insertion
 - ◆ packet from some other conversation received
 - ◆ header corruption
- Reordering
 - ◆ packets received in wrong order
 - ◆ usually due to retransmission
 - ◆ some routers also reorder

Packet error detection and correction

- Detection
 - ◆ Sequence numbers
 - ◆ Timeouts
- Correction
 - ◆ Retransmission

Sequence numbers

- In each header
- Incremented for non-retransmitted packets
- *Sequence space*
 - ◆ set of all possible sequence numbers
 - ◆ for a 3-bit seq #, space is {0,1,2,3,4,5,6,7}

Using sequence numbers

■ Loss

- ◆ gap in sequence space allows *receiver* to detect loss
 - ◆ e.g. received 0,1,2,5,6,7 => lost 3,4
- ◆ acks carry *cumulative* seq #
- ◆ redundant information
- ◆ if no ack for a while, *sender* suspects loss

■ Reordering

■ Duplication

■ Insertion

- ◆ if the received seq # is “very different” from what is expected
 - ◆ more on this later

Sequence number size

- Long enough so that sender does not confuse sequence numbers on acks
- E.g, sending at < 100 packets/sec (R)
 - ◆ wait for 200 secs before giving up (T)
 - ◆ receiver may dally up to 100 sec (A)
 - ◆ packet can live in the network up to 5 minutes (300 s) (*maximum packet lifetime*)
 - ◆ can get an ack as late as 900 seconds after packet sent out
 - ◆ sent out $900 * 100 = 90,000$ packets
 - ◆ if sequence space smaller, then can have confusion
 - ◆ so, sequence number $> \log(90,000)$, at least 17 bits
- In general $2^{\text{seq_size}} > R(2 \text{ MPL} + T + A)$

MPL

- How can we bound it?
- Generation time in header
 - ◆ too complex!
- Counter in header decremented per hop
 - ◆ crufty, but works
 - ◆ used in the Internet
 - ◆ assumes max. diameter, and a limit on forwarding time

Sequence number size (cont.)

- If no acks, then size depends on two things
 - ◆ reordering span: how much packets can be reordered
 - ◆ e.g. span of 128 => seq # > 7 bits
 - ◆ burst loss span: how many consecutive pkts. can be lost
 - ◆ e.g. possibility of 16 consecutive lost packets => seq # > 4 bits
 - ◆ In practice, hope that technology becomes obsolete before worst case hits!

Packet insertion

- Receiver should be able to distinguish packets from other connections
- Why?
 - ◆ receive packets on VCI 1
 - ◆ connection closes
 - ◆ new connection also with VCI 1
 - ◆ delayed packet arrives
 - ◆ could be accepted
- Solution
 - ◆ flush packets on connection close
 - ◆ can't do this for connectionless networks like the Internet

Packet insertion in the Internet

- Packets carry source IP, dest IP, *source port number*, *destination port number*
- How we can have insertion?
 - ◆ host A opens connection to B, source port 123, dest port 456
 - ◆ transport layer connection terminates
 - ◆ new connection opens, A and B assign the same port numbers
 - ◆ delayed packet from old connection arrives
 - ◆ insertion!

Solutions

- Per-connection *incarnation number*
 - ◆ incremented for each connection from each host
 - ◆ - takes up header space
 - ◆ - on a crash, we may repeat
 - ◆ need stable storage, which is expensive
- Reassign port numbers only after 1 MPL
 - ◆ - needs stable storage to survive crash

Solutions (cont.)

- Assign port numbers serially: new connections have new ports
 - ◆ Unix starts at 1024
 - ◆ this fails if we wrap around within 1 MPL
 - ◆ also fails if computer crashes and we restart with 1024
- Assign initial sequence numbers serially
 - ◆ new connections may have same port, but seq # differs
 - ◆ fails on a crash
- Wait 1 MPL after boot up (30s to 2 min)
 - ◆ this flushes old packets from network
 - ◆ used in most Unix systems

3-way handshake

- Standard solution, then, is
 - ◆ choose port numbers serially
 - ◆ choose initial sequence numbers from a clock
 - ◆ wait 1 MPL after a crash
- Needs communicating ends to tell each other initial sequence number
- Easiest way is to tell this in a *SYNchronize* packet (TCP) that starts a connection
- 2-way handshake

3-way handshake

- Problem really is that SYNs themselves are not protected with sequence numbers
- 3-way handshake protects against delayed SYNs

Loss detection

- At receiver, from a gap in sequence space
 - ◆ send a *nack* to the sender
- At sender, by looking at cumulative acks, and timing out if no ack for a while
 - ◆ need to choose timeout interval

Nacks

- Sounds good, but does not work well
 - ◆ extra load during loss, even though in reverse direction
- If nack is lost, receiver must retransmit it
 - ◆ moves timeout problem to receiver
- So we need timeouts anyway

Timeouts

- Set timer on sending a packet
- If timer goes off, and no ack, resend
- How to choose timeout value?
- Intuition is that we expect a reply in about one round trip time (RTT)

Timeout schemes

- Static scheme
 - ◆ know RTT *a priori*
 - ◆ timer set to this value
 - ◆ works well when RTT changes little
- Dynamic scheme
 - ◆ measure RTT
 - ◆ timeout is a function of measured RTTs

Old TCP scheme

- RTTs are measured periodically
- Smoothed RTT (*srtt*)
- $srtt = a * srtt + (1-a) * RTT$
- $timeout = b * srtt$
- $a = 0.9, b = 2$
- sensitive to choice of a
 - ◆ $a = 1 \Rightarrow timeout = 2 * initial\ srtt$
 - ◆ $a = 0 \Rightarrow no\ history$
- doesn't work too well in practice

New TCP scheme (Jacobson)

- introduce new term = mean deviation from mean (m)
- $m = |srtt - RTT|$
- $sm = a * sm + (1-a) * m$
- $timeout = srtt + b * sm$

Intrinsic problems

- Hard to choose proper timers, even with new TCP scheme
 - ◆ What should initial value of srtt be?
 - ◆ High variability in R
 - ◆ Timeout => loss, delayed ack, or lost ack
 - ◆ hard to distinguish
- Lesson: use timeouts rarely

Retransmissions

- Sender detects loss on timeout
- Which packets to retransmit?
- Need to first understand concept of error control window

Error control window

- Set of packets sent, but not acked
- 1 2 3 4 5 6 7 8 9 (original window)
- 1 2 3 4 5 6 7 8 9 (recv ack for 3)
- 1 2 3 4 5 6 7 8 9 (send 8)
- May want to restrict max size = window size
- Sender blocked until ack comes back

Go back N retransmission

- On a timeout, retransmit the entire error control window
- Receiver only accepts in-order packets
- + simple
- + no buffer at receiver
- - can add to congestion
- - wastes bandwidth
- used in TCP
- if packet loss rate is p , and

Selective retransmission

- Somehow find out which packets lost, then only retransmit them
- How to find lost packets?
 - ◆ each ack has a bitmap of received packets
 - ◆ e.g. cum_ack = 5, bitmap = 101 => received 5 and 7, but not 6
 - ◆ wastes header space
 - ◆ sender periodically asks receiver for bitmap
 - ◆ fast retransmit

Fast retransmit

- Assume cumulative acks
- If sender sees repeated cumulative acks, packet likely lost
- 1, 2, 3, 4, 5, 6
- 1, 2, 3 3 3
- Send $\text{cumulative_ack} + 1 = 4$
- Used in TCP

SMART

- Ack carries cumulative sequence number
- Also sequence number of packet causing ack
- 1 2 3 4 5 6 7
- 1 2 3 3 3 3
- 1 2 3 5 6 7
- Sender creates bitmap
- No need for timers!
- If retransmitted packet lost, periodically check if cumulative ack increased.